

**** This project was done with an '03 Expedition, using power folding mirrors from an '08 Expedition Limited. I make no promises that this will work with any other Ford model. Do at your own risk!****

I first attempted this project with the instructions and diagrams I found in a previous post on retrofitting mirrors to an '06 F-150. That met with negative results. One of the members I contacted told me he gave up and returned his parts.

This project is pretty straightforward. If you can install a CD player using instructions from Crutchfield, then this should pose no problem. On a scale of 1-10, I'd rate it a 4. Total time was 3.5 hours, but the majority of that was for taking off and putting back on interior panels. Once they are off, the work goes fast. **How much wire you use and how you run the wires will depend on where you decide you want to mount your switch!** I decided that I wanted my switch on the door, just under the existing power mirror adjustment switch.

While researching this project, I found that one of the biggest points of confusion for folks was whether or not they had Power Folding Mirrors in the first place. It's pretty easy to tell. The Driver's side mirror will have "Power Fold" stamped in the corner. OR, the part number tag will have "PF" in the icons (see pic). The picture shows my mirror. The icons "TS PF LH WHT" mean: Turn Signal, Power Folding, Left-Hand (Driver side) With Heat. At least, this is what the FORD guy told me.....**DO NOT BUY THE FORD FACTORY MIRROR SWITCH WITH THE BUILT-IN POWER FOLD!!** It will not work.



