

SHORT COMMANDS FOR THE VOICE COMMAND SYSTEM*

With short commands you can carry out certain functions directly, regardless of which menu

item is selected. Here are the important short commands for the voice command system.

Communication

Function	Command
For additional information, refer to the separate Owner's Manual.	
To open phone	›Phone‹
To dial phone number	›Dial number‹
To display phone book	›A to Z‹
To select from phone book	›Call ...‹ or ›Dial name‹
To display "Top 8"	›Top 8‹
Redialing	›Redial‹
To display "Received calls"	›Received calls‹
To display "Missed calls"	›Missed calls‹
To display "Bluetooth"	›Bluetooth‹
To open "MINI Contact"	›MINI Contact‹
To open "MINI Contact Numbers"	›MINI Contact numbers‹
To open "Nearest MINI dealer"	›Nearest MINI Center‹

Navigation

Function	Command
To open navigation 101	›Navigation‹
To display current position 114	›Current position‹
To open "Enter address" 96	›Enter address‹
To open "New destination" 96	›New destination‹

Function	Command
To display "Input map" 100	›Input map‹
To display address book 103	›Address book‹
To display destination list 102	›Destination list‹
To switch on destination guidance 107	›Start guidance‹
To switch off destination guidance 107	›Stop guidance‹
To display route criteria 105	›Route preference‹
To switch on voice instructions 110	›Navigation info on‹
To switch off voice instructions 110	›Navigation info off‹
To repeat voice instructions 110	›Repeat navigation info‹
To display arrow view 108	›Arrow display‹
To display map view 109	›Map‹, ›Map facing north‹, ›Map direction of travel‹ or ›Perspective‹
To open route 105	›Route‹
To open "New route" 111	›New route‹
To change scale 109	›Scale ... miles‹ or ›Scale ... feet‹
To display towns/cities and streets along the route 110	›Route list‹

Onboard info

Function	Command
To open "Car Data" 52	›Car data‹
To display computer 52	›Onboard info‹
To display trip computer 53	›Trip computer‹
To open speed limit 62	›Limit‹

Function	Command
To activate speed limit 62	›Limit on‹
To deactivate speed limit 62	›Limit off‹
To open stopwatch 63	›Stopwatch‹

Entertainment

Function	Command
Tone control 119	›Audio‹
To switch on radio 121	›Radio on‹ , ›FM on‹ or ›AM on‹
To open "FM" 121	›FM menu‹
To open "AM" 121	›AM menu‹
To open "All stations" 121	›FM all stations‹
To select radio station 121	›Station ...‹ e.g. ›Station WNYC‹ or ›Choose station‹
To open "Presets" 121	›FM presets‹ or ›AM presets‹
To select preset radio station 121	›Preset ...‹ e.g. ›Preset 1‹
To open "Manual" 122	›FM manual‹ or ›AM manual‹ or ›Choose frequency‹ or ›Frequency ... Megahertz‹
To open strongest radio station 122	›AM Autostore‹
To open "SAT" 126	›SAT radio menu‹
To switch on satellite radio 126	›SAT radio‹
To open "Presets" of the satellite radio 128	›SAT radio presets‹
To open "All channels" of the satellite radio 127	›SAT radio all channels‹
To open "Categories" of the satellite radio 127	›SAT radio categories‹
To open CD player 129	›CD menu‹

Function	Command
To switch on CD player 129	›CD‹
To open CD changer 129	›CD changer menu‹
To switch on CD changer 129	›CD changer‹
To select CD 129	›CD 1...6‹
To select track 130	›CD track ...‹
To select CD and track 130	›CD 1...6 track ...‹
To open DVD 129	›DVD player menu‹
To switch on DVD 129	›DVD player‹
To select DVD track 130	›DVD track ...‹
To start sound output for external audio device 135	›Audio Aux‹

Setup

Function	Command
To open setup	›Settings menu‹
"Display off" 20	›Display off‹
To open "Info sources"	›Info sources‹
To open "Settings"	›Settings‹
To open "Door locks" 27, 29	›Door locks‹
To open "Lighting" 46	›Lighting‹
To open "Service requirements" 56	›Service requirements‹
To open "Service" 56	›Service‹
To display "Check Control messages" 60	›Check Control messages‹
To activate speed limit 62	›Limit on‹
To deactivate speed limit 62	›Limit off‹
To set brightness of Control Display 64	›Brightness‹
To open "Units" 50	›Units‹

Function	Command
To open "Languages" 63, 110	›Language‹
To open "Time" 58	›Time‹
To open "Date" 59	›Date‹
To open "PDC" 65	›PDC‹
To open "FTM" 68	›FTM‹
To display "Bluetooth"	›Bluetooth‹